

LifeLine®

Champions of Safety

Mirror

Fitting Instructions

Take the assembled mirror out of the box and rotate the arm into position. Inside the box there is a small bag containing one 1/4 UNF x 1" countersunk screw and two No4 x 40 grub screws 5#.

- Unscrew 6# from the assembly and remove the countersunk washer and two rubber washers.
- Place the mirror assembly on the vehicle in the desired position and mark centre to be drilled. Drill the body work with a 1/4" hole (6,35mm).
- Remove 4# from the rest of the assembly.
- Sub assemble the counter sunk washer and one rubber washer with the appropriate length screw (This depends on the thickness of the body work).
- Insert the screw and washer assembly through the 1/4" hole from the inside of the body work.
- Add the second washer to the outside of the body work.
- Screw 4# on by hand.
- Using a 5/8 A/F spanner hold 4# in place and then tighten the countersunk screw with a 5/64 A/F Allen key.
- Screw the mirror assembly 2# to 4# by hand and position the mirror in place.
- Tighten 2# with a 3/4 A/F spanner while holding 1# with the 1/4 A/F spanner.
- Insert the two grub screws 5# using a 0.05" or 1,27mm Allen key. These are to lock the cover in place.
- Rotate the mirror body into position and tighten 7# with a 9/32 A/F Allen key.

